



## SUKSEN KUMIPUSKURI, SKI-DOO MUOVISUKSILLA 1993–2000



**~~12,20€~~ 9,90€**

Snowmobile SKI DOO ALPINE II (ROTAX 503) 1993 1995 Muovisuksilla  
Snowmobile SKI DOO ELAN (ROTAX 247) 1993 1996 Muovisuksilla  
Snowmobile SKI DOO FORMULA 500 (ROTAX 494) 1997 1998 Muovisuksilla  
Snowmobile SKI DOO FORMULA 583 (ROTAX 583) 1998 1998 Muovisuksilla  
Snowmobile SKI DOO FORMULA III (ROTAX 599) 1996 1997 Muovisuksilla  
Snowmobile SKI DOO FORMULA III 600 (ROTAX 599) 1998 1998 Muovisuksilla  
Snowmobile SKI DOO FORMULA III 600 LT (ROTAX 599) 1998 1998 Muovisuksilla  
Snowmobile SKI DOO FORMULA III 700 (ROTAX 699) 1998 1998 Muovisuksilla  
Snowmobile SKI DOO FORMULA MACH I (ROTAX 670) 1993 1993 Muovisuksilla  
Snowmobile SKI DOO FORMULA MACH I XTC (ROTAX 670) 1993 1993 Muovisuksilla  
Snowmobile SKI DOO FORMULA MACH Z (ROTAX 779) 1993 1993 Muovisuksilla  
Snowmobile SKI DOO FORMULA MX (ROTAX 467) 1993 1994 Muovisuksilla  
Snowmobile SKI DOO FORMULA MX XTC R (ROTAX 467) 1993 1993 Muovisuksilla  
Snowmobile SKI DOO FORMULA MXZ (ROTAX 467) 1994 1994 Muovisuksilla  
Snowmobile SKI DOO FORMULA MXZ (ROTAX 470) 1993 1993 Muovisuksilla  
Snowmobile SKI DOO FORMULA PLUS (ROTAX 582) 1993 1993 Muovisuksilla  
Snowmobile SKI DOO FORMULA PLUS EFI (ROTAX 582) 1993 1993 Muovisuksilla  
Snowmobile SKI DOO FORMULA PLUS II (ROTAX 582) 1993 1993 Muovisuksilla  
Snowmobile SKI DOO FORMULA PLUS X (ROTAX 583) 1993 1993 Muovisuksilla  
Snowmobile SKI DOO FORMULA PLUS XTC (ROTAX 582) 1993 1993 Muovisuksilla  
Snowmobile SKI DOO FORMULA S (ROTAX 377) 1995 1998 Muovisuksilla  
Snowmobile SKI DOO FORMULA SL (ROTAX 503) 1995 1998 Muovisuksilla  
Snowmobile SKI DOO FORMULA SLS (ROTAX 494) 1996 1996 Muovisuksilla  
Snowmobile SKI DOO FORMULA SS (ROTAX 670) 1995 1996 Muovisuksilla  
Snowmobile SKI DOO FORMULA ST (ROTAX 467) 1994 1994 Muovisuksilla  
Snowmobile SKI DOO FORMULA STX (ROTAX 583) 1995 1995 Muovisuksilla  
Snowmobile SKI DOO FORMULA Z (ROTAX 583) 1998 1998 Muovisuksilla  
Snowmobile SKI DOO FORMULA Z 670 (ROTAX 670) 1998 1998 Muovisuksilla  
Snowmobile SKI DOO GRAND TOURING (ROTAX 582) 1994 1994 Muovisuksilla  
Snowmobile SKI DOO GRAND TOURING 470 (ROTAX 467) 1995 1995 Muovisuksilla  
Snowmobile SKI DOO GRAND TOURING 500 (ROTAX 494) 1996 1998 Muovisuksilla  
Snowmobile SKI DOO GRAND TOURING 580 (ROTAX 582) 1995 1996 Muovisuksilla  
Snowmobile SKI DOO GRAND TOURING 583 (ROTAX 583) 1997 1998 Muovisuksilla  
Snowmobile SKI DOO GRAND TOURING 700 (ROTAX 699) 1998 1998 Muovisuksilla  
Snowmobile SKI DOO GRAND TOURING SE (ROTAX 670) 1994 1996 Muovisuksilla



Snowmobile SKI DOO GRAND TOURING SE (ROTAX 699) 1997 1998 Muovisuksilla  
Snowmobile SKI DOO GRAND TOURING XTC (ROTAX 582) 1994 1994 Muovisuksilla  
Snowmobile SKI DOO MACH I (ROTAX 670) 1994 1996 Muovisuksilla  
Snowmobile SKI DOO MACH I (ROTAX 699) 1997 1998 Muovisuksilla  
Snowmobile SKI DOO MACH Z (ROTAX 779) 1994 1996 Muovisuksilla  
Snowmobile SKI DOO MACH Z (ROTAX 799) 1997 1998 Muovisuksilla  
Snowmobile SKI DOO MACH Z LT (ROTAX 799) 1997 1998 Muovisuksilla  
Snowmobile SKI DOO MX (ROTAX 467) 1995 1995 Muovisuksilla  
Snowmobile SKI DOO MXZ (ROTAX 454) 1995 1995 Muovisuksilla  
Snowmobile SKI DOO MXZ 440 (ROTAX 454) 1996 1996 Muovisuksilla  
Snowmobile SKI DOO MXZ 440 F (ROTAX 443) 1997 1998 Muovisuksilla  
Snowmobile SKI DOO MXZ 500 (ROTAX 494) 1998 1998 Muovisuksilla  
Snowmobile SKI DOO MXZ 583 (ROTAX 583) 1996 1998 Muovisuksilla  
Snowmobile SKI DOO MXZ 670 (ROTAX 670) 1996 1998 Muovisuksilla  
Snowmobile SKI DOO MXZ X 440 (ROTAX 454) 1997 1998 Muovisuksilla  
Snowmobile SKI DOO SAFARI DELUXE (ROTAX 377) 1993 1994 Muovisuksilla  
Snowmobile SKI DOO SAFARI DELUXE L (ROTAX 377) 1994 1994 Muovisuksilla  
Snowmobile SKI DOO SAFARI L (ROTAX 377) 1993 1993 Muovisuksilla  
Snowmobile SKI DOO SAFARI RALLY (ROTAX 503) 1993 1993 Muovisuksilla  
Snowmobile SKI DOO SAFARI RALLY E (ROTAX 503) 1994 1994 Muovisuksilla  
Snowmobile SKI DOO SKANDIC 380 (ROTAX 377) 1995 1998 Muovisuksilla  
Snowmobile SKI DOO SKANDIC 500 (ROTAX 503) 1995 1998 Muovisuksilla  
Snowmobile SKI DOO SKANDIC II 377 (ROTAX 377) 1993 1994 Muovisuksilla  
Snowmobile SKI DOO SKANDIC II 377R (ROTAX 377) 1993 1994 Muovisuksilla  
Snowmobile SKI DOO SKANDIC II 503R (ROTAX 503) 1993 1994 Muovisuksilla  
Snowmobile SKI DOO SKANDIC II R (ROTAX 377) 1992 1992 Muovisuksilla  
Snowmobile SKI DOO SKANDIC II SLT (ROTAX 503) 1993 1994 Muovisuksilla  
Snowmobile SKI DOO SKANDIC SUPER WIDE TRACK (ROTAX 503) 1997 1997 Muovisuksilla  
Snowmobile SKI DOO SKANDIC SWT (ROTAX 503) 1998 1998 Muovisuksilla  
Snowmobile SKI DOO SKANDIC WIDE TRACK (ROTAX 503) 1995 1998 Muovisuksilla  
Snowmobile SKI DOO SKANDIC WIDE TRACK LC (ROTAX 494) 1998 1998 Muovisuksilla  
Snowmobile SKI DOO SUMMIT 470 (ROTAX 467) 1994 1994 Muovisuksilla  
Snowmobile SKI DOO SUMMIT 500 (ROTAX 494) 1996 1998 Muovisuksilla  
Snowmobile SKI DOO SUMMIT 583 (ROTAX 583) 1994 1998 Muovisuksilla  
Snowmobile SKI DOO SUMMIT 670 (ROTAX 670) 1995 1997 Muovisuksilla  
Snowmobile SKI DOO SUMMIT X 670 (ROTAX 670) 1998 1998 Muovisuksilla  
Snowmobile SKI DOO TOURING E (ROTAX 377) 1995 1998 Muovisuksilla  
Snowmobile SKI DOO TOURING E LT 2-UP (ROTAX 377) 1997 1997 Muovisuksilla  
Snowmobile SKI DOO TOURING LE (ROTAX 377) 1995 1995 Muovisuksilla  
Snowmobile SKI DOO TOURING LE (ROTAX 443) 1996 1998 Muovisuksilla  
Snowmobile SKI DOO TOURING SLE (ROTAX 503) 1995 1998 Muovisuksilla  
Snowmobile SKI DOO TUNDRA II (ROTAX 277) 1993 1998 Muovisuksilla



Snowmobile SKI DOO TUNDRA R (ROTAX 277) 1998 1998 Muovisuksilla

**SKU:** 88-517

**Moottorikelkkamerkki**

Ski-Doo