



KIMPEX TELASTON PYÖRÄ 136MM POLARIS MUSTA



~~50,00€~~ 42,00€

- Snowmobile POLARIS 120 XC/DRAGON/INDY LASTENKELKKA 2000 2006 1590317 (1,6)
Snowmobile POLARIS 340 CLASSIC (F/C FUJI) 2003 2006 1590275 (2,3)
Snowmobile POLARIS 340 EDGE TOURING (F/C FUJI) 2004 2004 1543018 (2,3)
Snowmobile POLARIS 340 INDY TOURING (F/C FUJI) 1999 2000 1590275 (2,3)
Snowmobile POLARIS 340 TOURING (F/C FUJI) 2001 2006 1590275 (2,3)
Snowmobile POLARIS 440 INDY TRANSPORT (F/C) 1996 1999 1543018 (2,3)
Snowmobile POLARIS 440 INDY XCR (L/C) 1998 1999 1543018 (2,3)
Snowmobile POLARIS 440 IQ L/C 2006 2006 1590317 (2,3)
Snowmobile POLARIS 440 PRO X (F/C LIBERTY) 2002 2003 1543018 (2,3)
Snowmobile POLARIS 440 PRO XR (L/C) 2004 2004 1543018 (2,3)
Snowmobile POLARIS 500 CLASSIC TOURING (L/C FUJI) 2002 2002 1543018 (2,3)
Snowmobile POLARIS 500 INDY (L/C FUJI) 2001 2006 1590275 (2,3)
Snowmobile POLARIS 500 INDY CLASSIC (L/C FUJI) 1997 2001 1543018 (2,3)
Snowmobile POLARIS 500 INDY CLASSIC TOURING (L/C FUJI) 1996 2000 1543018 (2,3)
Snowmobile POLARIS 500 INDY RMK (L/C FUJI) 1997 1999 1543018 (2,3)
Snowmobile POLARIS 500 INDY SUPER SPORT (F/C FUJI) 1997 1998 1590275 (2,3)
Snowmobile POLARIS 500 INDY TRAIL (F/C FUJI) 1997 1998 1543018 (2,3)
Snowmobile POLARIS 500 INDY TRAIL (L/C FUJI) 1999 1999 1543018 (2,3)
Snowmobile POLARIS 500 INDY TRAIL RMK (F/C FUJI) 1997 1998 1590318 (2,3)
Snowmobile POLARIS 500 INDY TRAIL TOURING (F/C FUJI) 1997 1998 1590275 (2,3,4)
Snowmobile POLARIS 500 INDY TRAIL TOURING (L/C FUJI) 1999 1999 1590275 (2,3,4)
Snowmobile POLARIS 500 INDY WIDE TRAK LX (L/C FUJI) 1997 1999 1590275 (2,3)



Snowmobile POLARIS 500 INDY XC (L/C LIBERTY) 1999 2000 1543018 (2,3)
Snowmobile POLARIS 500 INDY XC SP (L/C LIBERTY) 1999 2003 1543018 (2,3)
Snowmobile POLARIS 500 RMK (L/C LIBERTY) 2000 2002 1543018 (2,3)
Snowmobile POLARIS 500 WIDE TRAK LX (L/C FUJI) 2000 2006 1590275 (2,3)
Snowmobile POLARIS 500 XC EDGE (L/C LIBERTY) 2001 2002 1543018 (2,3)
Snowmobile POLARIS 500 XC SP (L/C) 2004 2007 1590275 (2,3)
Snowmobile POLARIS 500 XC SP EDGE (L/C LIBERTY) 2001 2002 1543018 (2,3)
Snowmobile POLARIS 550 CLASSIC (F/C FUJI) 2002 2006 1590275 (2,3)
Snowmobile POLARIS 550 INDY SUPER SPORT (F/C FUJI) 1999 2000 1590275 (2,3)
Snowmobile POLARIS 550 INDY TRAIL RMK (F/C FUJI) 1999 1999 1590318 (2,3)
Snowmobile POLARIS 550 PRO X (F/C FUJI) 2004 2004 1543018 (2,3)
Snowmobile POLARIS 550 SPORT TOURING 2001 2004 1543018 (2,3),ES
Snowmobile POLARIS 550 SUPER SPORT 2001 2006 1590275 (2,3)
Snowmobile POLARIS 550 TRAIL RMK (F/C FUJI) 2000 2007 1590318 (2,3)
Snowmobile POLARIS 550 TRAIL TOURING (F/C FUJI) 2000 2006 1543018 (2,3),1590275 (2,3,4)
Snowmobile POLARIS 600 CLASSIC (L/C LIBERTY) 2004 2006 1590275 (2,3)
Snowmobile POLARIS 600 CLASSIC TOURING (L/C LIBERTY) 2002 2002 1543018 (2,3)
Snowmobile POLARIS 600 EDGE TOURING (L/C LIBERTY) 2004 2004 1590275 (2,3),1543018 (2,3)
Snowmobile POLARIS 600 EDGE X (L/C LIBERTY) 2001 2001 1543018 (2,3)
Snowmobile POLARIS 600 H.O. FUSION (L/C LIBERTY) 2006 2006 1590275 (2,3)
Snowmobile POLARIS 600 H.O. RMK (L/C LIBERTY) 2006 2006 1590303 (2,3)
Snowmobile POLARIS 600 H.O. SWITCHBACK (L/C LIBERTY) 2006 2006 1590303 (2,3)
Snowmobile POLARIS 600 INDY XC (L/C) 1999 1999 1543018 (2,3)
Snowmobile POLARIS 600 INDY XC SP (L/C LIBERTY) 1999 2003 1543018 (2,3)
Snowmobile POLARIS 600 INDY XCR (L/C) 1997 1998 1543018 (2,3)
Snowmobile POLARIS 600 INDY XLT (L/C) 1997 1997 1543018 (2,3)
Snowmobile POLARIS 600 INDY XLT CLASSIC (L/C FUJI) 1998 1999 1543018 (2,3)
Snowmobile POLARIS 600 INDY XLT RMK (L/C) 1997 1997 1543018 (2,3)
Snowmobile POLARIS 600 INDY XLT SKS (L/C) 1997 1997 1543018 (2,3)
Snowmobile POLARIS 600 INDY XLT SPECIAL (L/C) 1998 1999 1543018 (2,3)
Snowmobile POLARIS 600 INDY XLT TOURING (L/C) 1998 1999 1543018 (2,3)
Snowmobile POLARIS 600 IQ DRAGON (L/C LIBERTY) 2008 2008 1590275 (2,3)
Snowmobile POLARIS 600 IQ LX (L/C LIBERTY) 2008 2008 1590275 (2,3)
Snowmobile POLARIS 600 IQ RMK (L/C LIBERTY) 2008 2008 1590275 (2,3)
Snowmobile POLARIS 600 IQ RR (L/C LIBERTY) 2008 2008 1590275 (2,3)
Snowmobile POLARIS 600 IQ SHIFT (L/C LIBERTY) 2008 2008 1590275 (2,3)
Snowmobile POLARIS 600 IQ SWITCHBACK (L/C LIBERTY) 2008 2008 1590275 (2,3)
Snowmobile POLARIS 600 IQ SWITCHBACK DRAGON (L/C LIBERTY) 2008 2008 1590275 (2,3)
Snowmobile POLARIS 600 IQ TOURING (L/C LIBERTY) 2008 2008 1590275 (2,3)
Snowmobile POLARIS 600 IQ WIDE TRAK (L/C LIBERTY) 2014 2014 1590317 (2,3)
Snowmobile POLARIS 600 PRO X (L/C LIBERTY) 2004 2004 1543018 (2,3)
Snowmobile POLARIS 600 PRO X2 (L/C LIBERTY) 2004 2004 1543018 (2,3)
Snowmobile POLARIS 600 RMK (L/C LIBERTY) 2004 2005 1590303 (2,3)



Snowmobile POLARIS 600 SWITCHBACK (L/C LIBERTY) 2004 2005 1590303 (2,3)
Snowmobile POLARIS 600 XC SP (L/C LIBERTY) 2004 2005 1590275 (2,3)
Snowmobile POLARIS 650 INDY RXL (L/C) 1991 1997 1543018 (2,3)
Snowmobile POLARIS 700 CLASSIC (L/C LIBERTY) 2006 2006 1590275 (2,3)
Snowmobile POLARIS 700 EDGE TOURING (L/C LIBERTY) 2004 2004 1543018 (2,3)
Snowmobile POLARIS 700 FUSION (L/C LIBERTY) 2006 2006 1590275 (2,3) HO
Snowmobile POLARIS 700 INDY XC (L/C LIBERTY) 1999 1999 1543018 (2,3)
Snowmobile POLARIS 700 INDY XC SP (L/C LIBERTY) 1999 2003 1543018 (2,3)
Snowmobile POLARIS 700 INDY XCR (L/C FUJI) 1999 1999 1543018 (2,3)
Snowmobile POLARIS 700 PRO X (L/C LIBERTY) 2003 2004 1543018 (2,3)
Snowmobile POLARIS 700 PRO X2 (L/C LIBERTY) 2004 2004 1543018 (2,3)
Snowmobile POLARIS 700 RMK (L/C LIBERTY) 2006 2006 1590303 (2,3)
Snowmobile POLARIS 700 RMK (L/C LIBERTY) 2001 2005 1590303 (2,3),1543018 (2,3)
Snowmobile POLARIS 700 TOURING (L/C LIBERTY) 2006 2006 1590303 (2,3)
Snowmobile POLARIS 700 XC SP (L/C LIBERTY) 2000 2005 1543018 (2,3)
Snowmobile POLARIS 750 FST CLASSIC (L/C 4-T TURBO) 2006 2006 1590303 (2,3)
Snowmobile POLARIS 750 FST SWITCHBACK (L/C 4-T TURBO) 2006 2006 1590303 (2,3)
Snowmobile POLARIS 750 FST TOURING (L/C 4-T TURBO) 2006 2006 1590303 (2,3)
Snowmobile POLARIS 750 IQ FST TOURING (L/C 4-T TURBO) 2007 2007 1590303 (2,3)
Snowmobile POLARIS 785 FRONTIER TOURING (4-T LIBERTY) 2003 2005 1590275 (2,3,4)
Snowmobile POLARIS 800 EDGE TOURING (L/C LIBERTY) 2004 2004 1590317 (2,3),1543018 (2,3)
Snowmobile POLARIS 800 INDY XC SP (L/C LIBERTY) 2003 2003 1590275 (2,3)
Snowmobile POLARIS 800 PRO X (L/C LIBERTY) 2003 2004 1543018 (2,3)
Snowmobile POLARIS 800 PRO X2 (L/C LIBERTY) 2004 2004 1543018 (2,3)
Snowmobile POLARIS 800 PRO XR (L/C LIBERTY) 2004 2004 1543018 (2,3)
Snowmobile POLARIS 800 RMK (L/C) 2001 2005 1590303 (2,3),1543018 (2,3)
Snowmobile POLARIS 800 SWITCHBACK (L/C LIBERTY) 2004 2005 1590303 (2,3)
Snowmobile POLARIS 800 XC SP (L/C LIBERTY) 2001 2005 1590275 (2,3)
Snowmobile POLARIS 800 XCR (L/C FUJI) 2000 2001 1543018 (2,3)
Snowmobile POLARIS 900 FUSION (L/C LIBERTY) 2005 2006 1590318 (2,3),SP
Snowmobile POLARIS 900 RMK (L/C LIBERTY) 2005 2006 1590318 (2,3),1543018 (2,3)
Snowmobile POLARIS 900 SWITCHBACK (L/C LIBERTY) 2006 2006 1590303 (2,3)

SKU: 84-0531-0

Moottorikelkkamerkki

Polaris